

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курган (3522)50-90-47
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саранск (8342)22-96-24
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35

Сыктывкар (8121)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://gea.nt-rt.ru/> || gsg@nt-rt.ru

МАШИНЫ ДЛЯ НАРЕЗКИ И ЗАГРУЗКИ ГОТОВОГО ПРОДУКТА FLEXLOADER

Технические характеристики



General info

The GEA FlexLoader for fully automated loading of sliced portions and minced meat into thermoformers and traysealers provides outstanding flexibility at a moderate investment, quickly changed over to accommodate various formats for the packaging machine.

- small footprint
- highly flexible for different formats of packaging machines and products

Working principle

The GEA FlexLoader is feeded with the sliced portions from a slicer for example. With the rejection of the feeding belt the die set is formed on the loading belt. After the aligning the portions are placed into the thermoformer.

- Precise loading of thermoformer
- Overlapping in many ways possible
- Different formats are easy to create

Performance

Fully automatic loading of pieces and sliced portions into packaging machines (thermoformer, traysealer, flow wrapper) -Overlapping or stacking of single products to portion possible. Highest flexibility - Easy change of format configuration just by changing the machine program - High positioning accuracy by intelligent distance measurement in combination with servo drives - Hygienic stainless steel construction for wash down cleaning - Fast and easy belt exchange without tools due to pneumatic tensioning -Mirrored machine setup possible

- Fully automatic loading
- Overlapping or stacking
- Highest flexibility
- High positioning accuracy
- Fast and easy belt exchange


Flexibility

Because of its small footprint the GEA FlexLoader fits well into a wide variety of line configurations. Flexibility is also given with different portion patterns that can be made with the FlexLoader, e.g. same distances of portions, grouping, shingle (forwards and backwards), uneven and straight stack, lateral grouping and lateral shingling.

- GEA FlexLoader covers many different line configurations
- Many different portion patterns can be made with GEA FlexLoader
- Left-hand version and right-hand version available

GEA FlexLoader – Portion Patterns

GEA



Hygiene

Easy and quick belt removal without tools. Hygiene design according: ANSI/NSF/3 – A14159-1 –2000 DIN EN 1672-2 - 1997 Sloped surfaces for draining, good accessibility for cleaning of all components. Special cleaning mode for easy sanitation.

- Sloped surfaces for draining
- Good accessibility for cleaning of all components
- Special cleaning mode
- Hygiene screws

Controls

Control of the GEA FlexLoader via own panel.

- Intuitive software
- Touchscreen to choose or change programs

Technical specifications

Label	GEA FlexLoader	Unit
Electric power	6	kW
Product height	max. 80	mm
Product width	max. 250	mm
Product length	max. 600	mm
Weight per portion	max. 1.500	gr
Thermoformer index	up to 600	mm
Film width	up to 600	mm
Die-set configuration	all	
Belt-width infeed belt	250	mm
Belt-width loading belt	600	mm
Stroke rejecting nose	700	mm
Capacity	max. 120	Portions/min

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курган (3522)50-90-47
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Ноябрьск (3496)41-32-12

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саранск (8342)22-96-24
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://gea.nt-rt.ru/> || gsg@nt-rt.ru