

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курган (3522)50-90-47
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Ноябрьск(3496)41-32-12

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саранск (8342)22-96-24
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://gea.nt-rt.ru/> || gsg@nt-rt.ru

СУШИЛКИ И УСТАНОВКИ ДЛЯ ОБРАБОТКИ ЧАСТИЦ HOTSWIRL

Технические характеристики





GEA HotSwirl Indirect Heater

Reliable hot air for spray
and fluid bed dryers

The GEA HotSwirl Indirect Heater provides reliable hot air at a consistent volume and temperature for GEA's range of spray dryers. As original equipment, the GEA HotSwirl complements GEA dryers perfectly ensuring compatibility, security of supply and simpler ongoing maintenance for customers.

Quality, reliability and efficiency The air heater is critical in all spray drying operations so, in developing HotSwirl, GEA engineers have focussed their attention on engineering quality and mechanical integrity. This means the heater will provide ongoing, reliable service throughout the service life of the entire installation.

HotSwirl is highly efficient; heat recovery can be selected as an integral part of the heater. This recovers heat from the exhaust gasses and returns it through the air inlet to minimize fuel costs; it saves CO₂ and helps provide the lowest possible TCO (Total Cost of ownership).

HotSwirl at a glance:

- Provides hot air at consistent temperature and volume for GEA spray dryers,
- GEA-engineered for proven reliability,
- High efficiency, comparable with best in class,
- Long service life,
- Single source supply for simple ongoing support from GEA,
- Horizontal or vertical orientation for easy installation,
- Can be located inside or outside,
- Available for new projects and retrofit,
- Wide range for all spray drying applications,
- Low NO_x burner as standard.

GEA HotSwirl, the practical option

HotSwirl Indirect Heater

New build or retrofit

GEA supplies HotSwirl with all new spray dryer installations to provide customers with the most cost-effective and practical heating option. Customers can also retrofit HotSwirl to existing plants during system upgrades especially where directly fired heaters are still being used.

HotSwirl range

The HotSwirl range of 14 heaters supplies hot air at 220°C – 250°C, at capacities from 2500Kg/hour to 50,000Kg/hour for larger installations. The standard pressure loss for all sizes is in the range of 20 mbar.

Two heaters or more can be used in parallel to supply the required volume of hot air for very large spray drying plants. Parallel configuration improves significantly the HotSwirl's ability to operate efficiently at part load.



HotSwirl range and capacities

HotSwirl [size]	Max air flow [kg/h]	Inlet [°C]	Outlet [°C]	Diameter [Øm]	Length [m]	Emergency load [kg]
1	2500	20	220-250	1.0	2.4	986
2	3150	20	220-250	1.1	2.7	1207
3	4000	20	220-250	1.3	2.9	1488
4	5000	20	220-250	1.4	3.3	1813
5	6300	20	220-250	1.6	3.7	2271
6	8000	20	220-250	1,7	4.1	2859
7	10000	20	220-250	1.9	4.6	3665
8	12500	20	220-250	2.2	5.1	4596
9	16000	20	220-250	2.4	5.7	5626
10	20000	20	220-250	2.7	6.3	7059
11	25000	20	220-250	3.0	7.1	9079
12	31500	20	220-250	3.3	8.0	12172
13	40000	20	220-250	3.7	9.0	15352
14	50000	20	220-250	4.2	10.1	21563

The heater can run up to an outlet temperature of 325°C, but at different flow conditions as stated in table

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курган (3522)50-90-47
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Ноябрьск(3496)41-32-12

Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саранск (8342)22-96-24
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35

Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35
Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Улан-Удэ (3012)59-97-51
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://gea.nt-rt.ru/> || gsg@nt-rt.ru